
List of figures

Figure 1	
Static discharge points	5
Figure 2	
Disk position	7
Figure 3	
Local and remote access to a system terminal	12
Figure 4	
Modem to a switch box and SDI and CPSI ports	13
Figure 5	
Sample enable/disable switch	21
Figure 6	
Sample LED indicator	23
Figure 7	
Sample maintenance display	26
Figure 8	
Manual initialize button and normal/maintenance switch on the CPU interface card	28
Figure 9	
Reload button on the changeover and memory arbitrator card	30
Figure 10	
NT8D22 System Monitor message flow	35
Figure 11	
PFTU configurations	37

Figure 12	
Power equipment designations from the master NT8D22 System Monitor	40
Figure 13	
Manual continuity tests: point-to-point configurations	51
Figure 14	
Manual continuity tests: loopback configurations	52